### **SERVICE MANUAL**

### **BG-1S** CHASSIS

MODEL

KV-T29SF1

COMMANDER DEST.

RM-870 Australia

CHASSIS NO.

SCC-K37B-A

MODEL

COMMANDER DEST. CHASSIS NO.





### **SPECIFICATIONS**

		Note
Power requirements	110-240 V AC, 50/60 Hz	
Power consumption (W)	Indicated on the rear of the TV	
Television system	B/G	
Color system	PAL, PAL 60, NTSC4.43, NTSC3.58 (AV IN)	
Channel coverage	VHF: 1 to 11/UHF: E21 to E69/CATV: S01 to S03, S1 to S41	
Audio output (speaker)	5W × 2	
Inputs	Antenna: 75 ohms	
	VIDEO IN jacks: phono jacks	
	Video: 1 Vp-p, 75 ohms	
	Audio: 500 mVrms, high impedance	
Outputs	Headphone jack: mini jack	
	MONITOR OUT jacks: phono jacks	
	Video: 1 Vp-p, 75 ohms	
	Audio: 500 mVrms	
Picture tube	29 in.	
Tube size (cm)	72	Measured diagonally
Screen size (cm)	68	Measured diagonally
Dimensions (w/h/d, mm)	686 × 617 × 537	
Mass (kg)	43	
Optional	TELETEXT ADAPTOR OPK-T200G	


Design and specifications are subject to change without notice.

### CAUTION

SHORT CIRCUIT THE ANODE OF THE PICTURE TUBE AND THE ANODE CAP TO THE METAL CHASSIS, CRT SHIELD, OR CARBON PAINTED ON THE CRT, AFTER REMOVING THE ANODE.

### SAFETY-RELATED COMPONENT WARNING!!


COMPONENTS IDENTIFIED BY SHADING AND MARK  $\triangle$  ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.



### Connections

# Connecting a VHF antenna or a combination VHF/UHF antenna — 75-ohm coaxial cable (round)


Attach an optional IEC antenna connector to the 75-ohm coaxial cable. Plug the connector into the T (antenna) socket at the rear of the TV.




## Connecting optional equipment

You can connect optional audio/video equipment to your TV such as a VCR, multi disc player, camcorder, video game or stereo system.

# Connecting video equipment using video input jacks




Front of TV



When using the video input jacks
Do not connect video equipment to the video input jacks at the
floot and the rear (VIDEO IN 1 for KV-T29) of your TV
simultaneously, otherwise the picture will not be displayed
properly on the screen.

# Connecting audio/video equipment using MONITOR OUT Jacks



When recording through the MONITOR OUT jacks
If you change the chancel or video input while recording with a
VGs, the channel or video input you are recording also will be
changed.

### 4 Getting Started

## Presetting channels manually **Presetting channels**

To change the channel for a particular program position or to receive a channel with a weak signal, preset the channel manually.

- 1 Press MANUAL PROGR.
- 2 Press PROGR +/- until the required program position appears on the screen.
- required channel picture appears on the 3 Press VOLUME +/- on the TV until the

You can preset up to 80 TV channels in numerical

sequence from program position 1.

Front of TV

Presetting channels automatically

4 Press MANUAL PROGR.

## Disabiling program positions

POWER

O SYSTEM MALMON

O i

0

By disabling unused or unwanted program positions, you can skip those positions when you press PROGR

- unwanted program position appears on the T Press PROGR +/- until the unused or

- Press MANUAL PROGR.

When the TV is in standby mode after pressing POWER, press POWER on the remote commander.

## Watching the TV

## remote commander.

To switch off the TV temporarily, press POWER on the

Switching off the TV



the STANDBY indicator may remain alight for a while. To switch off the TV completely, press POWER on the If the power on the TV is turned off in standby mode,

T Press POWER to turn the TV on.



## Watching the video input

When the TV is in standby mode after pressing POWER press POWER on the remote commander. 2 Select the TV channel you want to watch.

To select a channel directly

Press a number button.

### Press VIDEO/HOLD.





To watch TV, press TV.

For example: to select channel 25, press "-/--," and then "2" and "5."

To select a two-digit channel, press "-/--" before

the number buttons.

999 9999 9999




Muting the sound

Press MUTING.

Press PROGR +/- until the channel you want

appears.

To scan through channels



Operations 7

- 2 Press MANUAL PROGR.
- 3 Press PIC MODE on the remote commander.

**To cancel the skip setting** Preset the channel manually or automatically again.

E. AUTO PROGR

2 Press AUTO PROGR.

Press PROGR +/- to select the program position.

2 Press PROGR +/-to s 3 Press AUTO PROGR.

1 Press MANUAL PROGR.

To start presetting channels automatically from the specified program position

3 Press VOL +/- to adjust the volume.




1 Press POWER.

## Displaying on-screen information

### Press DISPLAY/REVEAL.

The program position, local system, and TV settings are displayed on the screen.




## Setting the Wake Up Timer

You can set the TV to turn on automatically after the period of time you want.

## Press WAKE UP/INDEX repeatedly to set the

The on-screen display appears and the WAKE UP indicator lights up.



### video input to be displayed using the Wake Up Timer, select the TV program or video Z If you want a particular TV program or

### 3 Press POWER on the remote commander or set the Sleep Timer to turn off the TV in standby mode.

To carnel the Wake Up Timer, press WAKE UP/INDEX repeatedly until "WAKE UP TIMER: OFF" appears, or turn of: the main power of the TV.

Notes

The Wake Up Timer starts immediately after the on-screen display disappears.

### 8 · | Operations


- The last TV program position or video mode just before the TV turns an using the Wake Up Timer.

   In obtained or timer.

   In obtained on using the Wake Up Timer, after TV is turned on using the Wake Up Timer, the TV automatically furnis into standig mode. When you want to continue watching the TV, press any button or control on the TV or remote commander.

## Setting the Sleep Timer

You can set the TV to turn off automatically after the period of time you want.




until "SLEEF TIMER: OFF" appears, or turn the TV off To cancel the Sleep Timer, press SLEEP repeatedly

### Changing the on-screen display language

on-screen display language. You can use buttons on both the remote commander and the TV. If you prefer Chinese to English, you can change the



### 1 Press SELECT until the screen appears as follow:



f Press SELECT until the item you want to

adjust appears.


Adjusting the picture and sound

### Note

 You can also use VOLUME +/- on the TV to select the on-screen display language.

### Adjusting the picture and sound

Each time you press SEUECT, the screen changes as



+ or -SELECT PIC MODE

## $\mathbf{Z}$ Press + or – to adjust the item.

Press PIC MODE until the mode you want

appears.

Selecting the picture mode



## 3 To adjust other items, repeat steps 1 and 2.

Each time you press PIC MODE, the screen changes as

follows:

## You can also use VOLUME +/- on the TV to adjust the picture

If the color of the picture is abnormal Press COLOR SYSTEM or adjust the color setting until and sound settings.

## Normally set COLOR SYSTEM to AUTO.

If you change the picture mode after the following adjustments, the adjustment changes in accordance with the

picture mode.

the color becomes normal.

STANDARD

### Front of TV



Operations | 9

## **Troubleshooting**

If you have any problems, read this manual again and check the countermeasure for each of the symptoms listed below.

If the problem persists, contact your nearest authorized service center or dealer.

### Snowy picture Noisy sound





◆Check the antenna connection on the TV ♣Check the antenna. and on the wall.

### **Dotted lines or stripes**



■ This may be caused by local interference (e.g. cars, neon signs, hair dryers, etc.). Adjust the antenna for minimum interference.

### Double images or "ghosts"



nearby mountains or buildings. A highly directional antenna may improve the → This may be caused by reflections from

### No picture No sound



♣ Press POWER.

→ Check the antenna connection.→ Check the VCR connections.

◆Check the power cord connection.

Check the standby mode.

### Good picture No sound





♣ Press VOLUME +.
♣ Press MUTING.

### No color



→ Adjust the COLOR level in the on-screen

◆Check the COLOR SYSTEM setting.

### TV cabinet creaks


◆ Even if the picture or the sound is normal, sometimes make the TV cabinet expand or contract, making a noise. This does not changes in the room temperature indicate a malfunction.

Note on the remote commander on everal models of the supplied remote commander is used on everal models of the TV. If you do not find instructions for some controls that are on the emote commander, that means your TV does not employ the features of those controls, e.g. TEXI.


Note on the TV SYSTEM button
The TV SYSTEM button is not used on your TV.

## **SECTION 2**


2-3. SERVICE POSITION



DISASSEMBLY



2-2. A BOARD REMOVAL




# 2-4. REPLACEMENT OF PARTS


2-5. DEMAGNETIZATION COIL REMOVAL


For replacement of the Multi Button, Power Button and Light Guide, cut the welded portions from them, exchange with the new parts, and fix them with screws (+BVTP) respectively.

# 2-4-1. REPLACEMENT OF MULTI BUTTON




2-4-2. REPLACEMENT OF LIGHT GUIDE, POWER BUTTON






Picture tube






## 2-6. PICTURE TUBE REMOVAL




## ·REMOVAL OF ANODE-CAP

NOTE: After removing the anode, short circuit the anode of the picture tube and the anode cap to the metal chassis, CRT shield or carbon paint on the CRT.


## REMOVING PROCEDURES



Turn up one side of the rubber cap in the direction indicated by the arrow (3).



② Using a thumb press down, then pull up the rubber cap firmly in the direction indicated by the arrow (b).



cap can be removed by turning up the rubber cap and pulling it up in the direction of the arrow  $\ensuremath{\mathfrak{G}}.$ ③ When one side of the rubber cap is separated from the anode button, the anode-

## HOW TO HANDLE AN ANODE-CAP

- Do not hurt the surface of anode-cap with sharp shaped objects.
- Do not press the rubber too hard so as not to damage the inside of anode-cap. A metal fitting called the shatter-hook terminal is built into the rubber. ⊝ ⊚
  - Do not turn the foot of rubber over too hard. @

The shatter-hook terminal will stick out or damage the rubber.



### SECTION 3 SET-UP ADJUSTMENTS

- The following adjustments should be made when a complete realignment is required or a new picture tube is installed.
- These adjustments should be performed with rated power supply voltage unless otherwise noted.

Controls and switch should be set as follows unless others	wise noted
PICTURE control	normal
BRIGHTNESS control	normal

Perform the adjustments in the following order:

- 1. Beam Landing
- 2. Convergence
- 3. Focus
- 4. White Balance

Note: Test Equipment Required:

- 1. Color-bar/Pattern Generator
- 2. Degausser
- 3. Oscilloscope

### Preparation:

- In order to reduce the influence of geomagnetism on the set's picture tube, face it east or west.
- Switch on the power and degauss with the degausser.

### 3-1. BEAM LANDING

- 1. Input a white signal with the pattern generator.
  - Contrast
    Brightness normal
- 2. Position neck assy as shown in Figure 3-1.
- 3. Set the pattern generator raster signal to green.
- 4. Move the deflection yoke to the rear and adjust with the purity control so that the green is at the center and the blue and the red take up equally sized areas on each side.
  - (See Figures 3-1 through 3-3.)
- 5. Move the deflection yoke forward and adjust so that entire screen is green. (See Figure 3-1.)
- 6. Switch the raster signal to blue, then to red and verify the condition.
- 7. When the position of the deflection yoke has been decided, fasten the deflection yoke with the screws.
- 8. If the beam does not land correctly in all the corners, use a magnet to adjust it. (See Figure 3-4.)




Fig. 3-1






Fig. 3-2





Fig. 3-3




### 3-2. CONVERGENCE

### Preparation:


- Before starting this adjustment, adjust the focus, horizontal size, and vertical size.
- Minimize the brightness setting.
- Provide dot pattern.


### (1) Horizontal and Vertical Static Convergence





- (Moving vertically), adjust the V.STAT magnet so that the red, green and blue dots are on top of each other at the center of the screen.
- (Moving horizontally), adjust the H.STAT VR so that the red, green and blue dots are on top of each other at the center of the screen.

If the V.STAT magnet is moved in the direction of the (a) and
 (b) arrows, the red, green and blue dots move as shown below.












Operation of BMC (Hexapole) Magnet
 If the red, green and blue dots are not balanced or aligned, then use the BMC magnet to adjust as described below.



 Then use the H.STAT VR to adjust the red, green and blue dots so that they coincide at the center of screen.
 The respective dot position resulting from moving each magnet interact, so be sure to perform adjustment while tracking.



- Y separation axis correction magnet adjustment.
- 1. Receive the cross-hatch signal and adjust PICTURE to "MIN" and BRIGHTNESS to "STANDARD".
- Adjust the Y separation axis correction magnet on the neck assembly so that the horizontal lines at the top and bottom of the screen are straight.



**Note:** 1) The Red and Blue magnets should be equally far from the horizontal center line.


2) Do not separate the Red and Blue magnets too far. (Less than 8 mm)

### (2) Dynamic Convergence Adjustment


### Preparation:


- Before starting this adjustment, adjust the horizontal static convergence and the vertical static convergence.
- 1. Slightly loosen the deflection yoke screws.
- 2. Remove the deflection yoke spacer.

- 3. Move the deflection yoke as shown in the figure below and optimize the convergence.
- 4. Tighten the deflection yoke screws.
- 5. Install the deflection yoke spacer.




### (3) Screen-corner Convergence





### 3-3. FOCUS ADJUSTMENT

Adjust FOCUS control on the flyback transformer for the best focus.



Note: Screen VR is not use.

### a. AN ITEM OF ADJUSTMENT

Item number	Adjustment item	Initial DATA	Note
09	RDR	26	WHITE POINT R
0A	GDR	20	WHITE POINT G
0B	BDR	20	WHITE POINT B

### b. METHOD OF CANCELLATION FROM SERVICE MODE


Set the standby condition (Press POWER button on the commander) and then press POWER button again, hereupon it becomes TV mode.

### c. METHOD OF WRITE FOR MEMORY

- 1) Set to Service Mode.
- 2) Press 1 (UP) and 4 (DOWN) to select an item of adjustments.
- 3) Press MUTING button and it will indicate WRITE on screen.
- 4) Press **0** button to write into memory.

### d. MEMORY WRITE CONFIRMATION METHOD


- 1) After adjustment, pull out the plug from AC outlet, and then plug into AC outlet again.
- 2) Turn the power switch ON and set to Service Mode.
- 3) Call the adjusted items again, confirm they were adjusted.



### 3-4. G2 (SCREEN) AND WHITE BALANCE ADJUSTMENTS

### 1. G2 (SCREEN) ADJUSTMENT (RV701)

- 1) Set the PICTURE and BRIGHTNESS to normal.
- 2) Put to VIDEO input mode without signals.
- 3) Connect R, G and B of the C board cathode to the oscilloscope.
- 4) Adjust G2 (RV701) volume to the value below.



### 2. WHITE BALANCE ADJUSTMENTS

- 1) Set to Service Mode.
- 2) Input an entire white signal.
- 3) Set the PICTURE to maximum.
- 4) Select RDR(09) with 1 and 4, and then set the level to 25 with 3 and 6.
- 5) Select GDR(0A) and BDR(0B) with 1 and 4 and adjust the level with 3 and 6 for the best white balance.
- 6) Write into the memory by pressing MUTING, then 0.

### SECTION 4 SELF DIAGNOSIS FUNCTION

If no acknowledgement is returned from a device which is turned "ON", the device has a problem. In this case, one of the LED's responding to the problem device will flicker a defined number of times.

Flickering is operated by lighting the LED's for 60ms each time.

The flickering frequency responding to each failed device is shown below.

Device	NONVOLA- TILE MEMORY		Y/C JUNGLE	_	_	AUDIO PROCESSOR (TA8776N)	
Flickering Frequency	1		3	_		6	

All the devices are checked one after another from the left of the table.


If an error is found, the responding LED will start flickering.


So, if more than 1 device have failed, only the one on the left side will flicker.

### SECTION 5 CIRCUIT ADJUSTMENTS

### 5-1. ADJUSTMENTS WITH COMMANDER

Service adjustments are made with the RM-870 that comes with this unit.





1, 4 Raise/lower the service item number
3, 6 Raise/lower the data
MUTING Writes
C Executes the writing

7, 0 All the data becomes the values in memory


7, 0 All the data becomes the values in memory


8, 0 All user control goes to the standard state

5, 0 Service data initialization (Be sure not to use usually.)

2, 0 Write 50Hz adjustment data to 60Hz, or viceversa.

The screen display is:






### 5-2. ADJUSTMENT METHOD


Item Number 08

This explanation uses V-SHIFT as an example.


- 1. Select 08 V-SHIFT with the 1 and 4 buttons.
- 2. Raise/lower the data with the 3 and 6 buttons.
- 3. Select the optimum state. (The standard is 0F for PAL reception.)
- 4. Write with the MUTING button.
- 5. Execute the writing with the 0 button. (The WRITE display returns to green SERVICE.)



Adjust with the 3 and 6 buttons.



Written with the MUTING.



Write executed with 0.

Use the same method for Items Number 00-49. Use 1 and 4 to select the adjustment item, use 3 and 6 to adjust, write with MUTING, then execute the write with 0.

### **Adjustment Item Table**

Item number	Adjustment Item	Data range	Initial data		Standard data		Note	Device
00	HSF	00-3F	24	50: 2F	60: 37		H SHIFT	TDA8375
01	HSZ	00–3F	23	50: 2E	60: 30		H SIZE	TDA8375
02	PAP	00-3F	21	50: 2B	60: 2B		PIN AMPLITUDE	TDA8375
03	CNP	00-3F	29	50: 26	60: 2F		CORNER PIN	TDA8375
04	TLT	00-3F	20	50: 20	60: 20		TILT	TDA8375
05	VSL	00-3F	20	50: 20	60: 20		V SLOPE	TDA8375
06	VAP	00-3F	1D	50: 20	60: 20		V AMPLITUDE	TDA8375
07	SCR	00-3F	20	50: 19	60: 1A		S CORRECTION	TDA8375
08	VSF	00-3F	20	50: 0F	60: 0F		V SHIFT	TDA8375
09	RDR	00–3F	<u> </u>				WHITE POINT R	TDA8375
0A	GDR	00-3F	20				WHITE POINT G	TDA8375
0B	BDR	00-3F	20				WHITE POINT B	TDA8375
_ <u>oc</u> _ :		00-02	— <del></del>	TV: 00	VIDEO: 00	TEXT: 01	PHI-1 TIME CONSTANT	TDA8375
0D	AGC	00-3F	06	TV: 28	VIDEO: 00	TEXT: 28		TDA8375
0E	vsw	00-01	01	TV: 00	VIDEO: 20	TEXT: 00		TDA8375
0F -	FOR							+
	DL DL	00–03 00–01	03				FORCED FIELD FREQ.	TDA8375
10 11	POC	00-01	00 00				INTERLACE	TDA8375
		— — — I			_ <b></b>	. — — <b>—</b>	SYNCHRO MODE FIX	TDA8375
12	VID	00–01	00				VIDEO IDENT MODE	TDA8375
13	HCO	00–01	00				EHT TRACKING MODE	TDA8375
14	EVG	00–01	00				ENABLE V GUARD	TDA8375
15	SBL	00–01	00				SERVICE BLANKING	TDA8375
<u> 16</u>	PRD_	_00-01	00				OVER-VOLTAGE INPUT	TDA8375
17	COR	00–01	00				NOISE CORING PEAK	TDA8375
18	PMX	00-3F	2D				PICTURE MAX DATA	TDA8375
19	PMI	00-3F	05				PICTURE MIN DATA	TDA8375
1A	SBR	00–7F	54	ļ			SUB-BRIGHTNESS	TDA8375
1B	SHU	00-0F	07				SUB-HUE	TDA8375
1C	SSH	00–03	— <del></del>	TV: 00	VIDEO:	02	SUB-SHARPNESS	TDA8375
1D	SC1	00–3F	1F	50: 22	60: 29		SUB-COLOR LOWER	TDA8375
1E	SC2	00-3F	0B	50: 0C	60: 0D		SUB-COLOR HIGHER	TDA8375
1F	AIP	00-7F	3F				ADJUSTMENT IF PLL	TDA8375
20	VZM	00-3F	19				VERTICAL ZOOM	TDA8375
36	BKP	00–3F	$-\frac{1}{00}$				Blk off Picture	CXP85200
37	HBL	00-3F	25				H Blk Left Width	CXP85200
38	HBR	00–3F	20				H Blk Right Width	CXP85200
39	VBH	00-7F	00				V Blk Hight Width	CXP85200
3A	VBL	00-FF	FF				V Blk Low Width	CXP85200
3B	ODL	00-FF	10				Power ON Delay	CXP85200
3C	OFR	00-0F	00				Remo. con. RGB OUT	CXP85200
3D	OFM	00-0F	00				Main power RGB OUT	CXP85200
3E	OSH	00-3F	0A				OSD Position H	CXP85200
3F	DKS	00-01	00				D/K STEREO Search	CXP85200
40	MUT	00-01	01				No Sync. Mute	CXP85200
41	DWZ	00-01	00				Diseble Widezoom	CXP85200
42	ABL	00-01	00				Bright ABL	CXP85200
43	DTV	00-01	00				Disable TV SYS Key	CXP85200
44	SCM	00-01	00				SECAM Trap Active	CXP85200
45	ROC	00-0F	07		07		Rotation Center	CXP85200
46	ROS	00-07	03		07 07		Rotation Step Wid	CXP85200
47	DVM	00-01	00		0,		Disable VM mode	CXP85200
48	OP0	00-FF	40		70		Option 0	CXP85200
49	OP1	00-FF	07		47		Option 1	CXP85200

### NOTE

• Standard Data: Those are the standard data values written on the microprocessor. Therefore, the data values of the modes are stored respectively in the memory.

In case of a device replacement, adjustment by rewriting the data value is necessary for some items.

- 50 ...... 50 Hz data60 ..... 60 Hz data
- Standard data listed on the adjustment item table are reference values, therefore it is different for every model.

### **ITEM INFORMATION**

10. DL: TV/MIX Mode 0=Interlace 1=Non-interlace, TEXT Mode 0=Non-interlace 1=Interlace

42. ABL: Bright ABL ON/OFF ON=1 OFF=0

48. OP0 • 49. OP1

Input data are different according to models.

AV INPUT:  $00 \rightarrow NO \text{ MODEL}$ ,  $01 \rightarrow MONO$ , CXA1315,  $10/11 \rightarrow STEREO$ , TDA8424

TV System : 00  $\rightarrow$  Multi model, 01  $\rightarrow$  B/G, 10  $\rightarrow$  D/K.I, 11  $\rightarrow$  B/G D/K

NTSC, SECAM, Chin

Shrp : Dinamic Mode @ 1  $\rightarrow$  Sharpness 50%, 0  $\rightarrow$  Sharpness 70%.

VM Operation :  $0 \rightarrow OFF$ ,  $1 \rightarrow ON$ 

### No. 48 OP0 \* Input data are different according to models

Item	_	AV Ir	nput	Shrp	_	_	_	Saudi
KV-T29SF1	0	1	1	1	0	0	0	0

### No. 49 OP1

Item	_	VM	_	TV Sy	/stem	NTSC	SECAM	Chin
KV-T29SF1	0	1	0	0	1	1	0	1

### 5-3. A BOARD ADJUSTMENT AFTER IC003 (MEMORY) REPLACEMENT

- 1. Enter to Service Mode.
- 2. Press commander buttons 5 and 0 (Data Initialize), and 2 and 0 (Data Copy) to initialize the data.
- 3. Call each item number, and check if the respective screen shows the normal picture.

In case some items are not well-adjusted, give them fine adjustment.

Write the data per each item number (MUTING + 0).

- 4. Select item numbers "48" (OP0) and "49" (OP1) and respectively set the bit per model with command buttons 3 and 6.
- 5. Press commander buttons (a) and (a) (Test Normal) to return to the data that was set on the shipment from the factory.(= Cancel Service Mode.)

### 5-4. PICTURE DISTORTION ADJUSTMENT


• Adjustments with commander

Item Number 00 - 08


00 HSF (H SHIFT)




01 HSZ (H SIZE)



02 PAP (PIN AMPLITUDE)




03 CNP (CORNER PIN)



04 TLT (TILT)



05 VSL (V SLOPE)




06 VAP (V AMPLITUDE)




07 SCR (S CORRECTION)



08 VSF (V SHIFT)





• Manual adjustments




SECTION 5
DIAGRAMS

5-1. BLOCK DIAGRAMS





### 5-2. CIRCUIT BOARDS LOCATION



### 5-3. SCHEMATIC DIAGRAMS AND PRINTED WIRING BOARDS

### Note:

- All capacitors are in μF unless otherwise noted. pF: μμF 50 WV or less are not indicated except for electrolytic and tantalums.
- All resistors are in ohms.

 $k\Omega = 100\Omega$ ,  $M\Omega = 1000k\Omega$ 

Indication of resistance, which does not have one for rating electrical power, is as follows.

Pitch: 5 mm Rating electrical power 1/4W (CHIP: 1/10W)

: nonflammable resistor.

- Δ : internal component.
- : panel designation, or adjustment for repair.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- Readings are taken with a color-bar signal input.

no mark : PAL

): SECAM

): NTSC 4.43

- Readings are taken with a 10  $M\Omega$  digital multimeter.
- Voltage are dc with respect to ground unless otherwise noted.
- Voltage variations may be noted due to normal production tolerances.
- All voltages are in V.
- \* : Can not be measured.
- Circled numbers are waveform reference.
- : B + bus.
- : signal path.

### RESISTOR : RN METAL FILM

	: RC	SOLID
	: FPRD	NONFRAMMABLE CARBON
•	: FUSE	NONFLAMMABLE FUSIBLE
	: RS	NONFLAMMABLE METAL OXIDE
	: RB	NONFLAMMABLE CEMENT
	: RW	NONFLAMMABLE WIREWOUND
	: ※	ADJUSTMENT RESISTOR
COIL	: LF-8L	MICRO INDUCTOR
CAPACITOR	: TA	TANTALUM
	: PS	STYROL
	: PP	POLYPROPYLENE
	:PT	MYLAR
	: MPS	METALIZED POLYESTER
	: MPP	METALIZED POLYPROPYLENE
	: ALB	BIPOLAR

Note: The component identified by shading and mark ⚠ are critical for safety. Replace only with part number specified.

HIGH TEMPERATURE

HIGH RIPPLE


: ALR


### **PRINTED WIRING BOARD**




[SYS CONTROLLER, TU, MEMORY, IF, Y/C JUNGLE H/V OUT, POWER SUPPLY, SECAM DECODER, AUDIO/VIDEO INPUT]

### - A Board -







)EO INPUT



### A BOARD WAVEFORMS










### NOTE:

The circuit indicated as left contains high voltage of over 600 Vp-p. Care must be paid to prevent an electric shock in inspection or repairing.







2 SYSI (M/S 3 EXTA MOND

9 GNĐ 10 LINTY DƯƯ

TO A1 BOARS

TO PICTURE TUBE

J 3 OND

2 200

TO C BOARD

AUDIO (R)

↑ TB51 NX-2743

**③** 

R852 0552 0.0047 280 250V 6557 1576

SYS CONTROLLER TU MEMORY IF. Y/C JUNGLE H/V OUT POWER SUPPLY SECAM DECODER AUDIO/VIDEO INPUT.

RES73

R816


B-SS5093<ME.>-A..

, ..... I


F8102 1. IUH

	KV-G25M1 (ME)	KV-G25M1(HK)	KV-G25M1(
CN106	NOT USED	NOT USED	NOT US
CN601	TO POWER CORD	TO POWER CORD	TO F1 BOARD
F601	T3.15A	T3.15A	NOT US
FB801	1.1uH	1.1uH	1.9uH
JR103	NOT USED	NOT USED	NOT US
JW032	NOT USED	NOT USED	15MM
JW132	NOT USED	NOT USED	15MM
Q302	NOT USED	NOT USED	NOT US
R020	NOT USED	NOT USED	NOT US
R316	NOT USED	NOT USED	NOT US
R317	NOT USED	NOT USED	NOT US
R327	0 : CHIP	0 : CHIP	0 : CHIP
R328	0 : CHIP	0 : CHIP	0 : CHIP
R329	C : CHIP	0 : CHIP	0 : CHIP
R334	NOT USED	NOT USED	NOT USE
R552	NOT USED	NOT USED	220K : CHIP
R <b>55</b> 3	NOT USED	NOT USED	0 : CHIP
R570	NOT USED	NOT USED	0 : CHIP
R635	NOT USED	NOT USED	NOTUSE

### A BOARD IC351 TDA4665T



### A BOARD IC300 TDA8366N3D



9V

01504 155119 F C1513

> 0551 CP080 V. DRIVE

> > 150

1 100mm R825 0858 PPRO CPORD H.CENT-

1.5 200V :PF

-13V

黎宁

なば

ΔA

DX

C548

JY050

1.51 977 1 - 5876 1.51 977 1 - 6.048 1.51 185 JM073 12.500

JMO82 SMH

C812 C919 C820 34:PP 550p 0801 24V ERC06-155

R895 70.82 185

(i)

CNDYI 6P WHT : DY

2002

1338 1337 1327 1 S1F
2 SYS1 (M/S)
3 EXTA MOND
4 GNO
5 SCL
6 SOA
7 9 (V)
9 GNO
10 LIH (TY OUT)
11 GNO

TO A1 BOARS CN1201

FOCUS

TO PICTURE TUBE

200V 200V 1000V CN851 4P WHT :HINI


TO C BOARD

CN701


### A BOARD \* MARK LIST


	KV-G25M1 (ME)	KV-G25M1(HK)	KV-G25M1(RUSS)	KV-G25M11
CN106	NOT USED	NOT USED	NOT USED	12P : BTOB
CN601	TO POWER CORD	TO POWER CORD	TO F1 BOARD CN1602	TO POWER CORD
F601	T3.15A	T3.15A	NOT USED	T3.15A
FB801	1.1uH	1.1uH	1.9uH	1.1uH
JR103	NOT USED	NOT USED	NOT USED	0 : CHIP
J <b>W</b> 032	NOT USED	NOT USED	15MM	NOT USED
JW132	NOT USED	NOT USED	15MM	NOT USED
Q302	NOT USED	NOT USED	NOT USED	2SC2412K
R020	NOT USED	NOT USED	NOT USED	100 : CHIP
R316	NOT USED	NOT USED	NOT USED	4.7K : CHIP
R317	NOT USED	NOT USED	NOT USED	1K : CHIP
R <b>32</b> 7	0 : CHIP	0 : CHIP	0 : CHIP	100 : CHIP
R328	0 : CHIP	0 : CHIP	0 : CHIP	100 : CHIP
R329	C : CHIP	0 : CHIP	0 : CHIP	100 : CHIP
R334	NOT USED	NOT USED	NOT USED	470 : CHIP
R552	NOT USED	NOT USED	220K : CHIP	220K : CHIP
R553	NOT USED	NOT USED	+	0 : CHIP
R570	NOT USED	NOT USED		0 : CHIP
R635	NOT USED	NOT USED	NOT USED	22 2W :RS


### A BOARD IC351 TDA4665T





### A BOARD IC300 TDA8366N3D














PRINTED WIRING BOARDS

**A1** 

[SIF]


C

[RGB OUT]


**V1** 

[TELE TEXT]


- C Board -




- V1 Board - (KV-G25M11 only)





- A1 Board -




### 5-4. SEMICONDUCTORS










2SC3209LK

2SD774-34




### TE:

- · Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

**SECTION 6 EXPLODED VIEWS** 

> The components identified by shading and mark ∆ are critical for safety.
> Replace only with part number specified.

### 6-1. CHASSIS



REF. NO.	PART NO.	$\underline{\text{DESCRIPTION}} \hspace{1cm} \text{.} \hspace{1cm} \underline{\text{REMARK}}$
1	4-048-702-11	DOOR, CONTROL
2		LABEL, CONTROL
3		LOCK, MINIATURE SIDE
4	X-4032-787-1	
. 6	4-048-691-01	
. 0		
7 8	4-048-687-01	BUTTON, MULTI GUIDE, LIGHT
-		BUTTON, POWER
9	4-037-613-01	
10		
11	1-504-305-11	SPEAKER (5X12CM)
12	4-043-388-01	SCREW, STEP TAPPING
13	4-390-505-01	SCREW (7), TAPPING
14	<b>∆</b> .8-733-242-05	PICTURE TURE (M60KWL10X)
15		DEFERCTION YOKE (Y25GIAS)
16		C BOARD, COMPLETE
17	3-704-495-01	SPACER. DY
18		HOLDER, HV CABLE
19		SPRING, TENSION
		COLL DEMACRETIZATION
21		BAND, DEGAUSSING COIL
		•
22	*4-042-988-01	
23	4-048-703-01	
24	4-049-130-01	
25		RAIL (L), GUIDE
26	*4-048-689-01	RAIL (R), GUIDE
27	* A-1241-190-A	F1 BOARD, COMPLETE (KV-G25M1 (RUSS))
28		BRACKET, F1 PC BOARD (KV-G25M1 (RUSS))
29		V1 BOARD, COMPLETE (KV-G25M11)
30		A1 BOARD, COMPLETE
		TUNER, KI-AC401
32	1-900-212-02	LEAD ASSY, FOCUS
33		TRANSPORMER, PLYBACK (NU-2743//MSB)
34		A BOARD, COMPLETE (KV-G25M1(ME))
0.		A BOARD, COMPLETE (KV-G25M1 (HK))
		A BOARD, COMPLETE (KV-G25M1 (RUSS))
		A BOARD, COMPLETE (KV-G25M11)
		HADEK ACOMO
36	4 1-574-062-22	OND PORK OTHE CONCRETE
		CASACON ENGINEERING
		ARESS ARES
	6.1-769-609-73	ero, puri gial directo
		(N-6250 DES)
37	1-452-032-00	MAGNET, DISC
38	Y_4207 214 1	PERMALOY ASSY, CORRECTION
39		
	4-043-141-01	LABEL, TERMINAL SHEET, BLIND .
40		
41		HOLDER, FBT
42	- 4-049-124-01	BRACKET, SPEAKER

1-544-453-21 SPEAKER (2CM)

### ·KV-G25M1/G25M11

### KV-G25M1/G25M11

### **SECTION 7 ELECTRICAL PARTS LIST**





NOTE:

The components identified by shading and mark  $\triangle$  are critical for safety. Replace only with part number specified.

When indicating parts by reference number,

- Items marked " \* " are not stocked since RESISTORS service. Some delay should be • All resistors are in ohms anticipated when ordering these items. • F : nonflammable
- All variable and adjustable resistors have characteristic curve B, unless otherwise

CAPACITORS • MF : μF, PF : μμF

	nclude the board	d name.	noted				COILS • MMH : µH, UH : µH		·
REF. NO.	PART NO.	DESCRIPTION		REMARK	REF. NO.	PART NO.	DESCRIPTION		REMAR
	* A-1292-869-A	A1 BOARD, COMPLETE			FB1201	1-412-911-11	<pre><ferrite bead=""> INDUCTOR, FERRITE BE</ferrite></pre>	AD	
		<capacitor></capacitor>					<ic></ic>		
C1201 C1202 C1203 C1204 C1205	1-104-665-11 1-164-004-11 1-164-004-11	CERAMIC CHIP 2.2MF ELECT 100MF CERAMIC CHIP 0.1MF CERAMIC CHIP 0.1MF CERAMIC CHIP 2.2MF	20% 10% 10%	16V 16V 25V 25V 16V	IC1202 IC1203 IC1204	8-759-070-71	IC AN5262-(NT) IC LA7016		
C1206 C1207 C1208 C1209 C1210	1-126-157-11 1-164-232-11 1-104-664-11 1-124-234-00	CERAMIC CHIP 0.01N ELECT 47MF ELECT 22MF	20% IF 10% 20% 20%	25V 16V 50V 16V 16V	Q1201 Q1202 Q1203	8-729-120-28	<transistor> TRANSISTOR 2SC1623-I TRANSISTOR 2SC1623-I TRANSISTOR 2SC1623-I</transistor>	.5L6	
C1211 C1212 C1213 C1214 C1215	1-104-664-11 1-164-505-11 1-164-505-11 1-124-907-11 1-124-907-11	CERAMIC CHIP 2.2MF CERAMIC CHIP 2.2MF ELECT 10MF	20% 7 20% 20%	16V 16V 16V 50V 50V	Q1204	8-729-120-28	TRANSISTOR 2SC1623-I <resistor></resistor>	.5L6	
C1216 C1217 C1218 C1219 C1221	1-104-664-11 1-164-505-11	CERAMIC CHIP 0.01	20%	16V 50V 16V 16V 16V	R1201 R1202 R1203 R1204 R1205	1-216-049-00 1-216-043-91 1-216-043-91	METAL GLAZE 1K METAL GLAZE 1K METAL GLAZE 560 METAL GLAZE 560 METAL GLAZE 560	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W
C1222 C1223 C1224 C1225 C1227	1-164-004-11 1-164-505-11	ELECT 47MF CERAMIC CHIP 0.1M CERAMIC CHIP 0.1M CERAMIC CHIP 2.2M CERAMIC CHIP 2.2M	F 10%	16V 25V 25V 16V 16V	R1206 R1207 R1208 R1209 R1210	1-216-059-00 1-216-049-00 1-216-049-00	METAL GLAZE 560  METAL GLAZE 2.7K  METAL GLAZE 1K  METAL GLAZE 1K  METAL GLAZE 27K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W
CF1201 CF1202 CF1203	2 1-567-101-11	<pre><filter> O FILTER, CERAMIC O FILTER, CERAMIC O FILTER, CERAMICO</filter></pre>			R1211 R1212 R1213 R1214 R1215	1-216-049-00 1-216-049-00 1-216-049-00 1-216-097-00	O METAL GLAZE 4.7K O METAL GLAZE 1K O METAL GLAZE 1K O METAL GLAZE 1K O METAL GLAZE 1K O METAL GLAZE 1OOK O METAL GLAZE 1K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W
		CONNECTOR>			R1216 R1217 R1218 R1219 R1220	1-216-097-00 1-216-081-00 1-216-081-00	O METAL GLAZE 100K O METAL GLAZE 22K O METAL GLAZE 22K O METAL GLAZE 22K O METAL GLAZE 22K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W
CN120	1 * 1-770-748-1	1 CONNECTOR, BOARD	TO BOARD	12P	R1221 R1222 R1223	1-216-081-0	0 METAL GLAZE 22K 0 METAL GLAZE 22K 0 METAL GLAZE 22K	5%	1/10W 1/10W 1/10W

لننسا	تت									
REF. NO.	PART NO.	DESCRIPTION		REMARK	REF. NO.	PART NO.	DESCRIPTION			REMARK
R1224 R1225			5% 1/ 5% 1/		C101		CERAMIC CHIP			50V
				·- ·	C102	1-136-169-00		0.22MF	5%	50V
R1226			5% 1/		C105	1-104-665-11 1-124-907-11		100MF 10MF	20% 20%	16V 50V
R1227	1-216-049-00	METAL GLAZE 1K METAL GLAZE 1K	5% 1/ 5% 1/		C106 C107	1-124-907-11	CERAMIC CHIP		20 <i>i</i> 0	50V
R1228 R1229	1 216 091 00	METAL GLAZE 1R METAL GLAZE 22K	5% 1/		C107	1-126-942-61		1000MF	20%	16V
R1229	1-216-081-00	METAL GLAZE 1K METAL GLAZE 22K METAL GLAZE 22K	5% 1/		0100	1 120 312 01	22201	2000		20.
111500	1 210 001 00				C109		CERAMIC CHIP		10%	50V
R1231	1-216-081-00	METAL GLAZE 22K	5% 1/	/10 <b>W</b>	C114		CERAMIC CHIP		5%	50V
					C115		CERAMIC CHIP		5%	50V
******	*******	********	*****	********	C116 C117	1-136-165-00	CERAMIC CHIP	0.1MF	5% 5%	50V 50V
	* A_1207_513_A	A BOARD, COMPLETE (KV	-G25M1	(ME))	CIII	1-103-117-00	CERCAMIC CITI	10011	J/I	301
	* A-1297-552-A	A BOARD, COMPLETE (KV	-G25M1	(HK))	C118	1-124-916-11	ELECT	22MF	20%	50V
		A BOARD, COMPLETE (KV			C119	1-163-059-00	CERAMIC CHIP	0.01MF		50V
	* A-1297-566-A	A BOARD, COMPLETE (KV	-G25M1	1)	C120	1-130-493-00		0.068MF		50V
		*******			C121	1-130-493-00		0.068MF		50V
	1 522 002 11	CLID BUCE			Ç122	1-104-665-11	ELECI	100MF	20%	16V
	1-533-223-11	CONNECTOR PIN (DY) 6P			C124	1-163-029-11	CERAMIC CHIP	0.0047MF		50V
		CASE (A), SHIELD			C125		CERAMIC CHIP			50V
	4-382-854-11	SCREW (M3X10), P, SW	(+)		C234	1-104-664-11		47MF	20%	16V
					C235	1-104-664-11		47MF	20%	16V
		-CADACTTOD.			C236	1-126-968-11	ELECT	100MF	20%	35V
		<capacitor></capacitor>			C237	1-104-665-11	ELECT	100MF	20%	16V
C001	1-163-011-11	CERAMIC CHIP 0.0015MF	10%	50V	C238	1-136-167-00			5%	50V
C002	1-124-916-11		20%	50V	C241	1-124-557-11	ELECT	1000MF	20%	25V
C003		CERAMIC CHIP 100PF	5%	50V	C242		CERAMIC CHIP		10%	50V
C004	1-124-925-11		20% 20%	50V 50V	C243	1-126-233-11	ELECT	22MF	20%	25V
C007	1-124-902-00	ELECT 0.47MF	20%	50 <b>v</b>	C244	1-124-557-11	ELECT	1000MF	20%	25V
C008	1-163-117-00	CERAMIC CHIP 100PF	5%	50V	C253	1-104-665-11		100MF	20%	16V
C009		CERAMIC CHIP 470PF	5%	50V	C258	1-136-169-00		0.22MF	5%	50V
C010			10%	25V	C300	1-104-664-11		47MF	20%	16V
C011	1-104-664-11	ELECT 47MF	20%	16V	C301	1-163-249-11	CERAMIC CHIP	82PF	5%	50V
C012	1-163-117-00	CERAMIC CHIP 100PF	5%	50V	C302	1-163-099-00	CERAMIC CHIP	18PF	5%	50V
C015	1-101-884-00	CERAMIC 56PF	5%	50V	C303	1-164-004-11	CERAMIC CHIP	0.1MF	10%	25V
C016	1-101-884-00		5%	50V	C304	1-164-004-11	CERAMIC CHIP	0.1MF	10%	25V
C017	1-163-117-00	CERAMIC CHIP 100PF	5%	50V	C305	1-164-004-11	CERAMIC CHIP	0.1MF	10%	25V
C018		CERAMIC CHIP 100PF	5%	50V	C306	1-164-004-11	CERAMIC CHIP	O. IMF	10%	25V
C030	1-163-125-00	CERAMIC CHIP 220PF	5%	50V	C307	1_164_004_11	CERAMIC CHIP	0 1MF	10%	25V
C031	1-124-903-11	ELECT 1MF	20%	50V	C308		CERAMIC CHIP		10%	25V
C034		CERAMIC CHIP 0.1MF	10%	25V	C309		CERAMIC CHIP		10%	25V
C035	1-163-009-11	CERAMIC CHIP 0.001M	10	50V	C310		CERAMIC CHIP		10%	25V
C036		CERAMIC CHIP 0.001M	10%	50V	C311	1-163-097-00	CERAMIC CHIP	15PF	5%	50V
C039	1-163-117-00	CERAMIC CHIP 100PF	5%	50V	C312	1-163-097-00	CERAMIC CHIP	15PF	5%	50V -
C040	1-163-117-00	CERAMIC CHIP 100PF	5%	50V	C313	1-104-665-11		100MF	20%	16V
C041	1-130-491-00	MYLAR 0.047MF		50V	C314	1-164-232-11	CERAMIC CHIP	0.01MF	10%	50V
C042	1-163-117-00	CERAMIC CHIP 100PF	5%	50V	C315	1-165-320-11	CERAMIC CHIP	0.47MF	10%	16V
C043		CERAMIC CHIP 220PF	10%	50V	C316	1-102-125-00	CERAMIC	0.0047MF	10%	50V
€044	1-163-117-00	CERAMIC CHIP 100PF	5%	50V	C319	1_164_004. 11	CERAMIC CHIP	O IME	10%	25V
C046	1-163-117-00	CERAMIC CHIP 100PF	5%	50V	C320	1-164-004-11	CERAMIC CHIP	0.1MF	10%	25V
C048		CERAMIC CHIP 0.1MF	10%	25V	C321	1-164-004-11	CERAMIC CHIP	0.1MF	10%	25V
C049		CERAMIC CHIP 0.1MF	10%	25V	C322		CERAMIC CHIP		10%	25V
C050	1-124-903-11		20%	50V	C323	1-163-109-00	CERAMIC CHIP	47PF	5%	50 <b>V</b>
C052	1-164-004-13	1 CERAMIC CHIP 0.1MF	10%	25 <b>V</b>	C224	1 164 227 11	CERAMIC CHIP	2 21/112		16V
COEE	1-126-941-1	1 ELECT 470MF	20%	16V	C324 C325	1-163-093-00	CERAMIC CHIP	10PF	5%	50V
C055 C057		1 CERAMIC CHIP 47PF	20% 5%	50V	C325	1-163-095-00	CERAMIC CHIP	12PF	5%	50V
C072	1-126-941-1		20%	16V	C327	1-163-093-00	CERAMIC CHIE	10PF	5%	50V
C074		1 CERAMIC CHIP 220PF	10%	50V	C329	1-163-016-00	CERAMIC CHIE	0.0039MF	10%	50V

### KV-G25M1/G25M11

RM-870



The components identified by shading and mark  $\underline{\Lambda}$  are critical for safety. Replace only with part number specified.

C1225 1-164-005-11 CERAMIC CHIP 0.47MF 25V D591 8-719-911-19 DIODE 1SS119-25 D601 8-719-052-84 DIODE RBV-406H-02 D602 8-719-108-18 THYRISTOR 5P4M D603 8-719-112-87 DIODE RD13EST1B	
C1513 1-124-122-11 ELECT 100MF 20% 50V D604 8-719-110-36 DIODE RU4DS	
D605	
CN101 *1-560-124-00 PLUG, CONNECTOR (2.5MM) 4P D609 8-719-510-26 DIODE DINL20 CN103 *1-564-509-11 PLUG, CONNECTOR 6P D610 8-719-510-26 DIODE DINL20 CN104 *1-770-747-11 CONNECTOR, BOARD TO BOARD 12P	
CN106 *1-770-747-11 CONNECTOR, BOARD TO BOARD 12P (KV-G25M11) D611 8-719-510-26 DIODE DINL20 (KV-G25M11) B01 8-719-945-80 DIODE ERC06-15S D802 8-719-900-26 DIODE ERD29-08J	
CN601 *1-580-843-11 PIN, CONNECTOR (POWER) CN602 *1-508-765-00 PIN, CONNECTOR (5MM PITCH) 3P  D851 8-719-302-43 DIODE EL1Z D852 8-719-028-72 DIODE RGP02-17EL-6433	
CN603 *1-508-786-00 PIN, CONNECTOR (5MM PITCH) 2P CN851 *1-508-766-00 PIN, CONNECTOR (5MM PITCH) 4P  D853 8-719-302-43 DIODE ELIZ D855 8-719-302-43 DIODE ELIZ D857 8-719-908-03 DIODE GP08D  D858 8-719-302-43 DIODE GP08D	
D858	
D891   8-719-945-80   DIODE ERC06-15S    -404-801-11   TRAP, CERAMIC   D901   8-719-054-60   DIODE LN0220022G    -409-429-11   TRAP, CERAMIC   D1201   8-719-121-24   DIODE RD9.1ESL    -409-327-00   TRAP, CERAMIC   C159   C169   C16	
<pre></pre>	
D001 8-719-109-81 DIODE RD4.7ESB2 D1505 8-719-109-84 DIODE RD5.1ESB1 D002 8-719-911-19 DIODE 1SS119-25 D003 8-719-041-97 DIODE MA113-(TX) D004 8-719-109-84 DIODE RD5.1ESB1 <fuse></fuse>	
D005 8-719-109-84 DIODE RD5. 1ESB1 F601 At 1-532-237-11 FUSE, TIME EAG (BET) 3.45A/2	<b>10</b> 1
D101 8-719-041-97 DIODE MA113-(TX) D102 8-719-109-81 DIODE RD4.7ESB2 D103 8-719-914-42 DIODE DA204K D251 8-719-911-19 DIODE 1SS119-25  CFERRITE BEAD>	(1)
D252 8-719-914-42 DIODE DA204K  FB101 1-410-397-21 FERRITE BEAD INDUCTOR 1.1UH  D301 8-719-041-97 DIODE MA113-(TX)  FB102 1-410-397-21 FERRITE BEAD INDUCTOR 1.1UH	
D302 8-719-041-97 DIODE MAI13-(TX) FB251 1-410-397-21 FERRITE BEAD INDUCTOR 1.1UH D303 8-719-041-97 DIODE MAI13-(TX) FB601 1-410-397-21 FERRITE BEAD INDUCTOR 1.1UH D304 8-719-041-97 DIODE MAI13-(TX) FB603 1-410-397-21 FERRITE BEAD INDUCTOR 1.1UH D305 8-719-041-97 DIODE MAI13-(TX)	
D306 8-719-911-19 DIODE 1SS119-25 FB610 1-410-397-21 FERRITE BEAD INDUCTOR 1.1UH D307 8-719-911-19 DIODE 1SS119-25 FB801 1-410-397-21 FERRITE BEAD INDUCTOR 1.1UH FB610 1-410-397-21 FERRITE BEAD INDUCTOR 1.1UH FB610 1-410-397-21 FERRITE BEAD INDUCTOR 1.1UH	11)
D308 8-719-109-54 DIODE RD2. 2ESB2 (KV-G25M1 (ME) / (HK), KV-G25M D310 8-719-041-97 DIODE MA113-(TX) FB801 1-420-872-00 COIL, AIR CORE (KV-G25M1 (RUS D311 8-719-109-68 DIODE RD3. 6ESB1	
D312 8-719-110-08 DIODE RD8.2ESB2 <ic> D313 8-719-041-97 DIODE MA113-(TX)</ic>	
D314 8-719-041-97 DIODE MA113-(TX) D351 8-719-908-03 DIODE GPO8D D401 8-719-421-40 DIODE MA77  D1002 8-759-805-37 IC L78LR05D-MA IC003 8-759-093-95 IC CAT24C04P IC004 8-741-790-11 ELEMENT, RAY-CATCHER SBX1790-	11
D402       8-719-911-19       DIODE 1SS119-25       IC102       8-759-157-40       IC UPC574J         D403       8-719-911-19       DIODE 1SS119-25       IC203       8-759-336-30       IC TA8223K         D513       8-719-908-03       DIODE GP08D       IC300       8-759-339-50       IC TDA8366N3D         D561       8-719-911-19       DIODE 1SS119-25       IC351       8-759-293-27       IC TDA4665	

The components identified by shading and mark ∆ are critical for safety.

Replace only with part number specified.



230000000000000000000000000000000000000												
7. NO.	PART NO.	DESCRIPTION			REMARK	REF. NO.	PART NO.	DESCRIPTION			REM	IARK
C330	1-164-004-11	CERAMIC CHIP	O IME	10%	25 <b>V</b>	C609	1-126-600-11	ELECT	100MF	20%	160V	
C332	1-136-165-00			5%	50V	C610	1-126-942-61		1000MF	20%	16V	
C333		CERAMIC CHIP		10%	25V	C612	1-102-228-00		470PF	10%	500V	
C335	1-102-973-00			5%	50V	C613	1-102-824-00		470PF	5%	50V	
C337	1-124-916-11			20%	50V							
						C614	1-124-557-11		1000MF	20%	25V	
C338		CERAMIC CHIP		10%	16V	C615 A	1-164-497-51			MANAGEN.	400V	
C339		CERAMIC CHIP		5%	50 <b>V</b>	C616	1-102-228-00		470PF	10%	500V	
C340		CERAMIC CHIP		10%	50 <b>V</b>	C620	1-136-619-11		0.0016MF		2KV	00000000000
C342		CERAMIC CHIP		10%	25V	C621 A	11-136-548-13	FIIM	0.1MF	20%	ZOUV	
C344	1-124-907-11	ELECT	10MF	20%	50 <b>V</b>	CCOO	1 100 202 00	MAT AD	0.04700	10%	2000	
COEO	1 104 664 11	DI DOT	470E	200	16V	C622 C623	1-106-383-00 1-124-120-11		0.047MF 220MF	20%	16V	
C350 C351	1-104-664-11	CERAMIC CHIP		20% 10%	25V	C624	1-126-942-61	FIRCT		20%	16V	
C352		CERAMIC CHIP		10%	25V	C625	1-102-074-00	CERAMIC		10%	50V	
C358		CERAMIC CHIP		10%	25V		1-164-497-51		470FF			
C359	1-104-665-11			20%	16V					2724594200	eer saaraatee araa aan	***************************************
0000	1 101 000 11	5250.	2002			C631	1-161-830-00	CERAMIC	0.0047MF	99%	500V	
367	1-164-004-11	CERAMIC CHIP	0.1MF	10%	25V	C801	1-123-024-21	ELECT	33MF		160V	
C368	1-164-004-11	CERAMIC CHIP	0.1MF	10%	25V	C802	1-106-367-00		0.01MF		200V	
C369	1-164-004-11	CERAMIC CHIP	0.1MF	10%	25V	C804		CERAMIC CHIP		10%	50V	
C370		CERAMIC CHIP		10%	25V	C805	1-102-244-00	CERAMIC	220PF	10%	500V	
C374	1-124-910-11	ELECT	47MF	20%	50V			ni nam		000	5077	
						C806	1-124-903-11		1MF	20%	50V	
C375	1-124-910-11		47MF	20%	50V	C807	1-136-540-11		0.82MF 0.047MF	5% 10%	200V 400V	
C402		CERAMIC CHIP		10% 20%	50V 50V	C808 C809	1-130-959-00 1-162-115-00		330PF	10%	2KV	
C403 C405	1-124-916-11	CERAMIC CHIP	22MF		50V 50V	C810	1-106-365-00		0.0082MF			
C405 C406		CERAMIC CHIP			50V	C610	1-100-303-00	MILAIK	0.0002MI	JJN	2001	
0400	1-103-017-00	CLICENIC CITI	0.0011111	10%	001	C811	1-162-318-11	CERAMIC	0.001M	10%	500V	
407	1-163-017-00	CERAMIC CHIP	0.0047MF	10%	50V	C812	1-136-617-11		0.019M	3%	2KV	
C408		CERAMIC CHIP			50V	C816	1-123-947-00	ELECT	10MF	20%	160V	
C409	1-163-109-00	CERAMIC CHIP	47PF	5%	50V	C820	1-162-135-11	CERAMIC	560PF	10%	2KV	
C410		CERAMIC CHIP		5%	50V	C821	1-106-391-12	MYLAR	0.1MF	10%	200V	
C411	1-163-113-00	CERAMIC CHIP	68PF	5%	50V							
						C822	1-136-541-11		1.5MF	5%	200V	
C412		CERAMIC CHIP		5%	50V	C823		CERAMIC CHIP		10%	50V	
C413	1-104-665-11	ELECT	100MF	20%	16V	C825	1-106-367-00		0.01MF	10%	200V 25V	
C414		CERAMIC CHIP		5%	50V	C850	1-124-480-11 1-104-574-11		470MF 0.0047MF	20%	2SV 2KV	
C415 C416		CERAMIC CHIP		10v 5%	50V 50V	C852	1-104-574-11	CERAMIC	U. UU4 / MG	10	ZILY	
C410	1-103-117-00	CERAMIC CHIF	10011	מכ	30¥	C853	1-162-318-11	CERAMIC	0.001MF	10%	500V	
<i>A</i> 17	1_163_117_00	CERAMIC CHIP	100PF	5%	50V	C854	1-124-480-11		470MF	20%	25V	
C418		CONDUCTOR, C			001	C856	1-162-318-11			10%	500V	
C419		CERAMIC CHIP		5%	50V	C857	1-130-493-00		0.068MF	5%	50V	
C420	1-104-664-11	ELECT	47MF	20%	16V	C860	1-102-228-00	CERAMIC	470PF	10%	500V ·	
C422	1-216-295-00	CONDUCTOR, C	HIP (2012	)					_			
					->	C861	1-107-654-11	ELECT	33MF		250V	
C423		CONDUCTOR, C		(201		C875	1-124-910-11		47MF	20%	50V	
C424		CONDUCTOR, C		(201		C876	1-108-702-11		0.068MF		100V	
C425		CERAMIC CHIP		10%	50V	C891	1-103-007-11	CERAMIC CHIP	0.033MF	10%	50V	
C501 C523	1-102-228-00		470PF	20%	500V 16V	C898	1-100-379-12	MILAN	U. UJJmr	10/0	1001	
C323	1-104-665-11	ELECT	100MF	20%	101	C901	1_163_133_00	CERAMIC CHIP	470PF	5%	50V	
C548	1-106-220-00	MVIAR	0.1MF	10%	100V	C902		CERAMIC CHIP		5%	50V	
C551	1-126-968-11		100MF	20%	35V	C1201	1-104-665-11		100MF	20%	16V	
C552	1-126-968-11		100MF	20%	35V	C1202		CERAMIC CHIP		10%	25V	
C553		CERAMIC CHIP			50V	C1204	1-104-665-11	ELECT	100MF	20%	16V	•
C554	1-102-244-00		220PF		500V							
						C1205		CERAMIC CHIP		10%	25V	
C555	1-101-804-00		10PF	5%	500V	C1210	1-104-665-11		100MF	20%	16V	
C562	1-104-665-11		100MF	20%	16V	C1213	1-124-903-11		1MF	20%	50V	
601	1-162-318-11			10%	500V	C1214	1-124-907-11		10MF	20%	50V	
C602	1-161-830-00		0.0047MF			C1217	1-104-665-11	ELECT	100MF	20%	16V	
C604	1-125-483-11	ELECT (BLOCK)	470MF	20%	400V	C1010	1 169 199 00	CEDANTO CUTE	100PF	<b>50</b> ′	50V	
C608	1 104 222 13	CEDANTO	470DE	10%	2KV	C1218 C1221		CERAMIC CHIP CERAMIC CHIP		5%	25V	
CUUO	1-104-332-11	CERAMIC	470PF	7 0,79	ZRV	1 01221	1-104-000-11	CERTIFIE CHIP	V. 4 ( IME		201	



REF. NO.	PART NO.	DESCRIPTION			REMARK	REF. NO.	PART NO.	DESCRIPTION		REMAL
R021	1-216-065-00	METAL GLAZE	4 7K 5	1/10	<b>W</b>	R266	1-216-089-00	METAL GLAZE	47K 5%	1/10W
R021 R027		METAL GLAZE		% 1/10		R301	1-216-073-00			1/10W
R028	1-216-025-00			% 1/10		R302	1-216-035-00			1/10W
R029		METAL GLAZE		% 1/10		R303	1-216-025-00	METAL GLAZE		1/10W
R030		METAL GLAZE		% 1/10						
						R304	1-216-025-00	METAL GLAZE	100 5%	1/10W
R031	1-216-049-00	METAL GLAZE	1K 5	% 1/10	)₩	R305	1-216-025-00			1/10W
R033	1-216-049-00	METAL GLAZE		% 1/10		R306	1-216-025-00			1/10W
R035	1-216-049-00			% 1/10		R307	1-216-025-00			1/10W
R036	1-216-049-00			% 1/10		R308	1-216-033-00	METAL GLAZE	220 5%	1/10W
R038	1-216-033-00	METAL GLAZE	220 5	% 1/10	)₩	DOOG	. 016 000 00	ABSOLUTE OF LOSS	000 58	1 (100
D040	1 016 000 00	MODEL CLATE	000 =	N 1/10	NIIT	R309	1-216-033-00 1-216-097-00			1/10\ 1/10\
R040	1-216-033-00			% 1/10		R310 R311	1-216-075-00			1/10W
R041	1-216-025-00 1-216-039-00	MEIAL GLAZE		% 1/10 % 1/10		R312	1-216-025-00			1/10W
R042 R043		METAL GLAZE		% 1/10 % 1/10		R312	1-216-089-00			1/10W
R044		METAL GLAZE		% 1/10		ROID	1-210-003-00	WELLIE GEREE	7/11 ON	1/ 1011
KO44	1-210-075-00	METTE GENER	1011 0	W 1/10	/1I	R314	1-216-025-00	METAL GLAZE	100 5%	1/10W
R046	1-216-097-00	METAL GLAZE	100K 5	% 1/10	)W	R315	1-216-081-00			1/10W
R047		METAL GLAZE		% 1/10		R316	1-216-065-00			1/10W
R048				% 1/10					(KV-	-G25M11)
R049	1-216-121-00	METAL GLAZE	1M 5	% 1/10	)W	R317	1-216-049-00	METAL GLAZE		1/10W
R050	1-216-057-00	METAL GLAZE	2.2K 5	% 1/10	W(					-G25M11)
					_	R318	1-216-099-00	METAL GLAZE	120K 5%	1/10W
R051				% 1/10						1 /2 AW
R052				% 1/10		R319	1-216-109-00			1/10W
R054				% 1/10		R320	1-216-083-00			1/10W
R057			1K 5	6 1/10 6% 1/10		R321 R322	1-216-689-11 1-216-061-00			50% 1/10W - 1/10W
R059	1-210-000-00	METAL GLAZE	4.7K 3	78 1/10	Jπ	R324	1-216-121-00			1/10W
R067	1_216_033_00	METAL GLAZE	220 5	% 1/10	)W	Nos4	1-210-121-00	METHE GENEE	III ON	1/ 1011
R068		METAL GLAZE		% 1/10		R327	1-216-025-00	METAL GLAZE	100 5%	1/10 <b>W</b>
R071		METAL GLAZE		% 1/10						-G25M11)
R076		METAL GLAZE		% 1/10		R327	1-216-295-00	CONDUCTOR, C	HIP (2012) (	KV-G25M1)
R077	1-216-025-00	METAL GLAZE	100 5	5% 1/10	WC	R328	1-216-025-00	METAL GLAZE	100 5%	1/10W
										-G25M11)
R090		METAL GLAZE		5% 1/10		R328		CONDUCTOR, C		
R101		METAL GLAZE		3% 1/10		R329	1-216-025-00	METAL GLAZE		1/10W
R102		METAL GLAZE		5% 1/10					(KV-	-G25M11)
R103		METAL GLAZE		5% 1/1(		Doon	1 216 205 00	CONDUCTOR, C	/ (פוחפ) מזעי	AN COEMIN
R113	1-216-081-00	METAL GLAZE	22K 5	5% 1/10	UTT	R329 R330		METAL GLAZE		1/10W
R114	1 216 041 00	METAL GLAZE	470	5% 1/10	OM	R332		METAL GLAZE		1/10W
R114		) METAL GLAZE		5% 1/10		R334		METAL GLAZE		1/10W
R116		METAL GLAZE		5% 1/1						-G25M11)
R117		METAL GLAZE		5% 1/10		R335	1-216-073-00	METAL GLAZE	10K 5%	1/10W
R118		METAL GLAZE		5% 1/1						
						R336		METAL GLAZE		1/10W
R119	1-216-055-00	METAL GLAZE	1.8K	5% 1/1		R338		METAL GLAZE		1/10W
R120		METAL GLAZE		5% 1/1		R339		METAL GLAZE		1/10W
R131		METAL OXIDE			2₩ F	R340		METAL GLAZE		1/10W
R180		METAL GLAZE		5% 1/1		R341	1-216-049-00	METAL GLAZE	1K 5%	1/10 <b>W</b>
R181	1-216-033-00	) METAL GLAZE	220	5% 1/1	UW	R351	1 216 001 00	METAL GLAZE	10 50	1/10W
D100	1 216 022 0	NETAL CLASE	220	5% 1/1	Λ <b>W</b>	R355		METAL GLAZE		1/10W
R182		) METAL GLAZE 1 METAL GLAZE		5% 1/1		R356		METAL GLAZE		1/10W
R242 R243		) METAL GLAZE		5% 1/1		R403		METAL GLAZE		1/10W
R243 R244	1-216-073-0	) METAL GLAZE		5% 1/1		R406		METAL GLAZE		1/10W
R245		O METAL GLAZE		5% 1/1			000			•
.WIO	1 220 001-0			, <b>-</b>	•	R407	1-216-063-00	METAL GLAZE	3.9K 5%	1/10W
R250	1-216-295-0	O CONDUCTOR,	CHIP (2012)			R408	1-216-055-00	METAL GLAZE	1.8K 5%	1/10W
R251	1-216-295-0	O CONDUCTOR,	CHIP (2012)			R409		METAL GLAZE		1/10W
R252	1-249-411-1	1 CARBON	330	5% 1/		R410		METAL GLAZE		1/10\
R253		O METAL GLAZE		5% 1/1		R411	1-216-057-00	METAL GLAZE	2.2K 5%	1/10W
R254	1-249-389-1	1 CARBON	4.7	5% 1/	4W			ARTON AT AT A CO	C 01/2	1 /1 000
		0 1mm11 01 1 ==	0.07	-N 1/2	OW	R412		METAL GLAZE		1/10W
R265	1-216-061-0	O METAL GLAZE	, 3.3K	5% 1/1	U₩	R413	1-216-057-00	METAL GLAZE	2.2K 5%	1/10W

The components identified by shading and mark \( \frac{\Lambda}{\text{ are critical for safety.}} \)
Replace only with part number specified.



EF. NO.	PART NO.	DESCRIPTION REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
IC354 IC401	8-759-251-56 8-759-800-65	IC LA7910	Q208 Q210 Q301	8-729-900-98	TRANSISTOR DTC144EK TRANSISTOR DTC143TK TRANSISTOR DTC114EK	
IC521 IC551 IC601	8-759-195-63 8-759-801-98 8-749-010-84		Q302	8-729-120-28	TRANSISTOR 2SC1623-L5L6	-G25M11)
IC602 IC603 A	8-749-920-61		Q303 Q402	8-729-922-66	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC2410SN	
IC801 IC1210	8-759-100-96 8-759-100-96	IC UPC4558G2 IC UPC4558G2	Q403 Q404	8-729-900-98	TRANSISTOR DTC143TK TRANSISTOR DTC143TK	
		<jack></jack>	Q405 Q406 Q407 Q408	8-729-216-22 8-729-216-22	TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G TRANSISTOR 2SC1623-L5L6	
J251 J1201 J1202	1-770-785-11 1-770-660-11 1-695-238-11	JACK JACK BLOCK, PIN 4P JACK BLOCK, PIN 2P	Q409 Q410	8-729-216-22	TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G	
		<chip conductor=""></chip>	Q411 Q412 Q413 Q414	8-729-120-28 8-729-120-28 8-729-900-98	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR DTC143TK TRANSISTOR 2SC1623-L5L6	
JR103	1-216-295-00	CONDUCTOR, CHIP (2012) CONDUCTOR, CHIP (2012) (KV-G25M11) CONDUCTOR, CHIP (2012)	Q415 Q416 Q417	8-729-900-98 8-729-120-28 8-729-900-98	TRANSISTOR DTC143TK TRANSISTOR 2SC1623-L5L6 TRANSISTOR DTC143TK	
		<coil></coil>	Q418 Q561		TRANSISTOR DTC143TK TRANSISTOR 2SA1091-0	
L002 L003 L101 L301 L401	1-410-470-11 1-408-411-00 1-410-396-41 1-408-609-41 1-410-498-11	INDUCTOR 15UH FERRITE BEAD INDUCTOR 0.45UH INDUCTOR 33UH	Q601 Q801 Q802 Q821 Q902	8-729-140-96 8-729-016-32 8-729-018-99	TRANSISTOR 2SC2412K TRANSISTOR 2SD774-34 TRANSISTOR 2SC4927-01 TRANSISTOR 2SD2394-F TRANSISTOR DTC144EK	
L402 L403 L404 L405 L406	1-410-510-11 1-410-510-11 1-410-508-11 1-410-508-11 1-410-507-11	INDUCTOR 12UH INDUCTOR 8.2UH INDUCTOR 8.2UH	Q903 Q1201 Q1202 Q1203 Q1204	8-729-120-28 8-729-120-28 8-729-120-28	TRANSISTOR DTC144EK TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SA1162-G	
L407 L408 L409 L410 L411	1-535-303-00 1-535-303-00	INDUCTOR 15UH LEAD, JUMPER (5. OMM) LEAD, JUMPER (5. OMM) LEAD, JUMPER (5. OMM) LEAD, JUMPER (5. OMM)	Q1207 Q1208 Q1265 Q1513	8-729-120-28 8-729-900-98	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR DTC143TK TRANSISTOR 2SC1623-L5L6	
L802 L804 L805 L807 L808	1-459-907-11 1-459-390-00 1-412-553-11	COIL, DYNAMIC CONVERSION CHOKE COIL, HORIZONTAL LINEARITY COIL (WITH CORE)	R001 R002 R003 R004 R007	1-216-065-00 1-216-065-00	METAL GLAZE       4.7K       5%         METAL GLAZE       4.7K       5%         METAL GLAZE       4.7K       5%	1/10\\ 1/10\\ 1/10\\ 1/10\\
L850	1-408-947-00		R008	1-216-049-00	METAL GLAZE 1K 5%	1/10\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\
Q03 <b>O</b>	8-729-120-28	<transistor> TRANSISTOR 2SC1623-L5L6</transistor>	R009 R010 R012 R013	1-216-049-00 1-216-049-00 1-216-017-00 1-216-049-00	METAL GLAZE 1K 5% METAL GLAZE 47 5%	1/10W 1/10W 1/10W 1/10W
Q031 Q108 )109 Q110 Q202	8-729-120-28 8-729-120-28 8-729-120-28	TRANSISTOR 2SA1162-G TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SA1162-G	R014 R015 R018 R019	1-216-049-00 1-216-043-91 1-216-033-00 1-216-101-00	METAL GLAZE 1K 5% METAL GLAZE 560 5% METAL GLAZE 220 5% METAL GLAZE 150K 5%	1/10W 1/10W 1/10W 1/10W
Q207		TRANSISTOR 2SA1162-G	R020	1-216-025-00		1/10W G25M11)



The components identified by shading and mark ∆ are critical for safety.

Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION		REMARK	REF. NO.	PART NO.	DESCRIPTION		REMARI.
R910 R911 R913 R914 R915	1-216-071-00 1-216-041-00 1-216-041-00	METAL GLAZE 3.3 METAL GLAZE 8.2 METAL GLAZE 470 METAL GLAZE 470 METAL GLAZE 8.2	2K 5% ) 5% ) 5%	1/10W 1/10W 1/10W 1/10W 1/10W	<b>7605</b> 2 T801	**************************************	TRANSFORMER, TRANSFORMER,	CONVERGER (SELECTION OF THE PILITER HORIZONTAL DE	NVE.
R1201 R1202 R1203 R1205 R1206	1-216-049-00 1-216-089-00 1-216-023-00	METAL GLAZE 82 METAL GLAZE 1K METAL GLAZE 47F METAL GLAZE 82 METAL GLAZE 47F	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		<b>61-453-190-</b> 11	<thermistor></thermistor>	(NX-2743)	(ALSB)
R1211 R1212 R1215 R1216 R1218	1-216-049-00 1-216-113-00 1-216-113-00	METAL GLAZE 68 METAL GLAZE 1K METAL GLAZE 470 METAL GLAZE 470 METAL GLAZE 470	5% OK 5% OK 5%	1/10W 1/10W 1/10W 1/10W		1_810_961_11 1_8=598_323_00	<tuner></tuner>		
R1219 R1220 R1221 R1227 R1228	1-216-049-00 1-216-073-00 1-216-689-11	METAL GLAZE 10H METAL GLAZE 10H METAL GLAZE 10H METAL GLAZE 39H METAL GLAZE 1K	5% { 5% { 5%	1/10W 1/10W 1/10W 1/10W 1/10W	X101 X300 X358	1-577-082-11 1-404-835-31 1-567-505-11			
R1229 R1230 R1231 R1232 R1233	1-216-073-00 1-216-049-00 1-216-063-00	METAL GLAZE 470 METAL GLAZE 101 METAL GLAZE 1K METAL GLAZE 3.9 METAL GLAZE 2.2	K 5% 5% 9K 5%	1/10W 1/10W 1/10W 1/10W 1/10W	X443		OSCILLATOR, (	CRYSTAL ************************************	******
R1235 R1239 R1240 R1241 R1243	1-249-389-11 1-216-025-00 1-216-049-00	METAL GLAZE 391 CARBON 4.7 METAL GLAZE 100 METAL GLAZE 1K METAL GLAZE 100	7 5% 0 5% 5%	1/10W 1/4W F 1/10W 1/10W 1/10W	C701	1-162-114-00	<capacitor></capacitor>	0.0047MF 2KV	
R1245 R1246 R1247 R1248 R1249	1-216-037-00 1-216-041-00 1-216-051-00	METAL GLAZE 330 METAL GLAZE 330 METAL GLAZE 470 METAL GLAZE 1.1 METAL GLAZE 470	0 5% 0 5% 2K 5%	1/10W 1/10W 1/10W 1/10W 1/10W	C702 C704 C708 C709	1-102-074-00 1-130-202-00 1-102-114-00 1-102-114-00 1-102-114-00	FILM CERAMIC CERAMIC	0.001MF 10% 0.022MF 5% 470PF 10% 470PF 10%	50V 400V 50V 50V
R1513 R1514 R1515	1-216-073-00 1-216-065-00	METAL GLAZE 101 METAL GLAZE 4. METAL GLAZE 101	K 5% 7K 5%	1/10W 1/10W 1/10W	C712 C713 C714 C716	1-101-361-00 1-102-971-00 1-101-361-00 1-124-122-11	CERAMIC CERAMIC CERAMIC	150PF 5% 82PF 5% 150PF 5% 100MF 20%	50V 50V 50V 50V
		<switch></switch>					<connector></connector>		
S601 2 S801 S901 S902 S903	1-572-707-11 1-570-577-11 1-570-577-11	SWITCH, PUSH (AN SWITCH, LEVER SWITCH, PUSH SWITCH, PUSH SWITCH, PUSH	C POWER)			* 1-508-766-00 * 1-564-509-11 1-695-915-11	PLUG, CONNECT TAB (CONTACT)	TOR 6P	4P
S904 S905		SWITCH, PUSH SWITCH, PUSH <spark gap=""></spark>			D701 D702 D703 D704 D705	8-719-911-19 8-719-911-19 8-719-911-19	<pre><diode> DIODE 1SS119- DIODE 1SS119- DIODE 1SS119- DIODE 1SS119- DIODE 1SS119-</diode></pre>	-25 -25 -25	
SG801	1-519-422-11	<filter></filter>	WAY 200		D706 D707 D708 D709	8-719-911-19 8-719-911-19 8-719-911-19	DIODE 1SS119- DIODE 1SS119- DIODE 1SS119- DIODE 1SS119-	-25 -25 -25	
SWF401	1-760-771-11	FILTER, SURFACE	WAVE		D710	8-119-911-19	DIODE 1SS119-	-45	

The components identified by shading and mark  $\triangle$  are critical for safety. Replace only with part number specified.



ÆF. NO.	PART NO.	DESCRIPTION				REMARK	REF. NO.	PART NO.	DESCRIPTION			,	DENTA DIS
	-					TC:IIII(I	ider . No.	TAKT NO.	DESCRIFTION			1	REMARK
R414			470		1/10W		R617	1-215-924-00		15 <b>K</b>	5%	3₩	F
R415		METAL GLAZE	220		1/10W		R619	1-249-377-11		0.47	5%	1/4W	F
R416	1-216-033-00	METAL GLAZE	220	5%	1/10W		R621	1-211-748-11		5.6	5%	5 <b>W</b>	F
R417	1 216 022 00	METAL CLASE	000	-~	1 /1 000		R622	1-217-190-21		0.15	10%		F
R417 R418	1-216-033-00	METAL GLAZE	220 680		1/10W 1/10W		R623	1-247-807-31	CARBON	100	5%	1/4₩	
R419	1-216-049-00		1K		1/10W		R624	1-215-881-11	METAL OVIDE	15	EN	OUT	ъ
R420		METAL GLAZE	390		1/10W		R625	1-249-424-11		15 3.9K	5% 5%	2₩ 1/4₩	F
R421		METAL GLAZE			1/10W		R626	1-249-420-11		1.8K	5%	1/4W	
					_,		R627	1-249-417-11		1K	5%	1/4W	
R422	1-216-027-00		120	5%	1/10W		R628	1-249-417-11		1K	5%	1/4W	
R423	1-216-029-00		150		1/10W								
R424		METAL GLAZE	2.2K		1/10W		R629	1-249-401-11		47	5%	1/4W	
R425 R426	1-216-039-00		390		1/10W		R635	1-215-882-00	METAL OXIDE		5%	2₩	F
R420	1-216-029-00	METAL GLAZE	150	5%	1/10W		DCOC		100m17 07770m			25M11)	_
R427	1-216-037-00	METAL CLATE	330	E9/	1/10W		R636		METAL OXIDE		5%	3₩	F
R428	1-216-081-00		22K		1/10W		R801 R802	1-215-920-11 1-249-387-11		3.3K	5%	3₩	F
R429		METAL GLAZE			1/10W		ROUZ	1-245-301-11	CARDON	3.3	5 <b>%</b>	1/4₩	F
R430			470		1/10W		R804	1-216-049-00	METAL CLAZE	1K	5%	1/10W	
R431	1-216-081-00	METAL GLAZE	22K		1/10W		R805	1-216-081-00	METAL GLAZE	22K		1/10₩	
							R808	1-535-303-00	LEAD, JUMPER	(5. OMM)	0.0	2, 20	
R432	1-216-041-00		470		1/10W		R809	1-247-756-11	CARBON	2.2K	5%	1/2W	F
R433	1-216-081-00		22K		1/10W		R811	1-216-346-00	METAL OXIDE	0.56	5%	1₩	F
R434		METAL GLAZE			1/10W		7044						
R435 R436	1-216-041-00 1-216-081-00		470 22K		1/10W 1/10W		R812	1-216-075-00		12K		1/10W	
1/450	1-210-001-00	MEIAL GLAZE	22N	370	1/10#		R816 R820	1-249-430-11 1-216-053-00		12K	5%	1/4W	
R437	1-216-081-00	METAL GLAZE	22K	5%	1/10W		R821	1-215-910-00	METAL GLAZE	1. ON	5% 5%	1/10\\ 3\\\	F
R440	1-216-029-00				1/10W	1	R822		METAL OXIDE		5%	3₩ 1₩	r F
R441	1-216-021-00				1/10W	ŀ	11000	1 210 120 00	MIDITED ONIDE	210	3.0	ıπ	r
R521	1-216-049-00	METAL GLAZE			1/10W		R823	1-247-756-11	CARBON	2.2K	5%	1/2₩	F
R552		METAL GLAZE			1/10W		R825	1-249-392-11	CARBON	8.2	5%	1/4W	F
		(KV-G25M1 (RU	SS)/(HK),i	KV-G	25M11)	-	R826	1-216-059-00		2.7K	5%	1/10W	
DEED	1 016 005 00	COMPLICTOR O	UTD (0010)			-	R827	1-216-097-00		100K		1/10W	
R553		CONDUCTOR, CI (KV-G25M1 (RU			OEM11)		R828	1-216-063-00	METAL GLAZE	3.9K	5%	1/10W	
R555	1-249-429-11		33)/(nk/,1 10K		23M11) 1/4₩	1	R829	1-216-053-00	METAL CLASE	1 517	-~	1 (100	
R556		METAL GLAZE			1/10₩	İ	R831	1-216-426-11		1.5K	5% 5%	1/10\ 1\	F
R557		METAL GLAZE			1/10W		R832	1-216-057-00		2.2K		1/10W	Г
R56O	1-216-295-00	CONDUCTOR, C	HIP (2012)	)			R834	1-216-073-00				1/10W	
254							R851	1-249-382-11		1.2		1/4W	F
R561	1-249-421-11		2•: 2K		1/4W	_							
R562 R563	1-249-420-11 1-247-885-00	CARBUN	1.8K	5%	1/4W	F	R852	1-249-923-11		1K	5%	1/4₩	F
R564	1-216-091-00		180K 56K		1/4W		R853	1-249-377-11		0.47	5%	1/4W .	
R565		METAL GLAZE			1/10\\ 1/10\\		R854 R855	1-249-377-11 1-202-818-00		0.47		1/4W	F
	1 210 001 00	METTE COME	OUL	UN	1/ 1011	I	R856	1-249-425-11		1K 4.7K		1/2\ 1/4\	
R566	1-216-065-00	METAL GLAZE	4.7K	5%	1/10W		1.000	1 010 100 11	CALIDON	4. III	JA	1/4#	
R569	1-247-883-00		150K		1/4W	İ	R857	1-249-438-11	CARBON	56K	5%	1/4W	
R57 <b>O</b>		CONDUCTOR, C					R858	1-216-370-11	METAL OXIDE	1.2	5%	2₩	FZ
DCOO		(KV-G25M1 (RUS					R860	1-247-887-00		220K	5%	1/4W	
R603	1-249-416-11		820	5%	1/4W	F	R881	1-216-043-91	METAL GLAZE	560		1/10W	
R604	1-249-416-11	CARBUN	820	5%	1/4W	F	R882	1-216-059-00	METAL GLAZE	2.7K	5%	1∕10₩	
R606	1-215-915-11	METAL OXIDE	470	5%	3 <b>W</b>	F	R883	1-216-121-00	METAL CLASE	1M	E0/	1 /1 007	
R608		LEAD, JUMPER		UN	311	.	R895	1-216-348-00		0.82	5% 5%	1/10W 1W	F
R609	1-249-381-11		1	5%	1/4W		R898	1-249-421-11		2.2K		1/4W	I.
R61O		METAL OXIDE	15K	5%	3₩	F	R902	1-216-065-00		4.7K		1/10W	
R611	1-202-933-61	FUSIBLE	0.1	10%	1/2₩	F	R904	1-216-065-00	METAL GLAZE			1/10W	
D619	1 040 055 ::	CARRON	0.45	<b>-</b> 0.		_	Bar-						
R612 ₹613	1-249-377-11			5%	1/4W	F		1-216-049-00				1/10W	
R614	1-249-377-11 1-215-877-11		0.47 22K	5% 5%	1/4W 1W	F   F		1-216-049-00				1/10W	
R615	1-249-389-11		4.7	5% 5%	1/4W	r		1-216-055-00 1-216-055-00	METAL GLAZE	1 6K 1-9¥		1/10W	
		METAL					R909	1-216-061-00	METAL GLAZE	3.3K		1/10\ 1/10\	
~~~~				ere en initial la	orani e i i i i i i i i i i i i i i i i i i	(24.270()00()000(00)			يطلقان بددد	J. OIL	ON.	A/ AVIT	
						Ī							





The components identified by shading and mark ⚠ are critical for safety.
Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION		REMARK	REF. NO.	PART NO.	DESCRIPTION		REMARI
		<transformer></transformer>		-			<ic></ic>		
T1601 2 T1602 2	K 1-424-436-11 K 1-424-436-11	TRANSPURMER LINE FILTE TRANSPURMER LINE FILTE	R R		IC01 IC02	8-759-324-28 8-759-298-63	IC P83C654 IC SAA5281ZP/E		
******	********	*******	*****	******			<chip conductors<="" td=""><td>,</td><td></td></chip>	,	
	* A-1347-103-A	V1 BOARD, COMPLETE (KV-	G25M11	)	JR02	1_216_295_00	CONDUCTOR, CHIP		
		<capacitor></capacitor>			JR02 JR03 JR04 JR07 JR08	1-216-295-00 1-216-295-00 1-216-295-00	CONDUCTOR, CHIP CONDUCTOR, CHIP CONDUCTOR, CHIP CONDUCTOR, CHIP	(2012) (2012) (2012)	
C01 C02	1-163-037-11 1-124-907-11	CERAMIC CHIP 0.022MF 10 ELECT 10MF 20	0% 25 0% 50						
C03 C04 C05	1-163-037-11	CERAMIC CHIP 0.022MF 10 CERAMIC CHIP 0.1MF 10	0% 25 0% 25 0% 50	5V	L01	1-410-464-11	<coil> INDUCTOR 3.3</coil>	BUH BUH	
C06 C07 C08 C09	1-163-009-11 1-163-097-00 1-164-004-11	CERAMIC CHIP 0.001MF 15 CERAMIC CHIP 15PF 5 CERAMIC CHIP 0.1MF 1	% : 0% 25	0 <b>V</b> 50 5 <b>V</b>	L03 L04 L05 L06	1-410-464-11 1-410-464-11 1-410-464-11 1-410-464-11	INDUCTOR 3.3 INDUCTOR 3.3	SUH SUH SUH	
C10				5 <b>V</b>			<transistor></transistor>		
C11 C12 C13 C14 C15	1-164-004-11 1-163-009-11	CERAMIC CHIP 0.1MF 1 CERAMIC CHIP 0.001MF 1 CONDUCTOR, CHIP (	0% 50 (2012)	5V 0V 5V	Q01 Q02 Q03 Q04 Q05	8-729-900-53 8-729-120-28 8-729-120-28	TRANSISTOR 2SC10 TRANSISTOR DTC1 TRANSISTOR 2SC10 TRANSISTOR 2SC10 TRANSISTOR 2SA1	14EK 623-L5L6 623-L5L6	
C16 C17 C19 C22 C23	1-164-004-11 1-124-907-11	CERAMIC CHIP 0.1MF 1 CERAMIC CHIP 0.1MF 1 ELECT 10MF 2	.0% 2 .0% 2	0V 5V 5V 0V	Q06 Q07 Q08 Q09	8-729-019-01 8-729-140-96	TRANSISTOR 2SC10 TRANSISTOR 2SD2: TRANSISTOR 2SD7' TRANSISTOR DTA1	394-EF 74-34	
C25	1-124-907-11			0V 6V			<resistor></resistor>	•	
C26 C27	1-124-119-00 1-104-665-11	ELECT 100MF 2	20% 1	6V	DO1	1 216 061 00	METAL GLAZE 3.	3¥ 5¥	1/10₩
C28 C29	1-163-099-00	CERAMIC CHIP 18PF 5	5% 5	0V 0V 0V	R01 R02 R03 R04	1-216-057-00 1-216-085-00	METAL GLAZE 33. METAL GLAZE 33. METAL GLAZE 10	2K 5% K 5%	1/10W 1/10W 1/10W
C30 C31				60V	R05	1-216-057-00	METAL GLAZE 2.	2K 5%	1/10W
		<connector></connector>			R06 R07 R08	1-216-025-00 1-216-025-00	METAL GLAZE 12 METAL GLAZE 10 METAL GLAZE 10	0 5% 0 5%	1/10W 1/10W 1/10W
CN01	*1-770-748-11	CONNECTOR, BOARD TO BO.	ARD 12	P	R09 R10		METAL GLAZE 2. METAL GLAZE 27		1/10W 1/10W
		<diode></diode>			R11 R12	1-216-069-00 1-216-057-00	METAL GLAZE 6. METAL GLAZE 2.	2K 5%	1/10W 1/10W
D001	8-719-105-51	DIODE RD3.6M-B1 DIODE DAN202K			R13 R16	1-216-061-00	) METAL GLAZE 3. ) METAL GLAZE 10		1/10W 1/10W
D03 D04	8-719-105-91	DIODE RD5.6M-B2			R17		METAL GLAZE 4.	7K 5%	1/10W
D05 D06		DIODE DAP202K DIODE DAN202K			R18 R19 R20	1-216-049-00 1-216-049-00	METAL GLAZE 2.  METAL GLAZE 1K  METAL GLAZE 1K	5% 5%	1/10W 1/10W 1/10W 1/10W
		<ferrite bead=""></ferrite>			R21 R22		) METAL GLAZE 4. ) METAL GLAZE 47		1/10W
FB01	1-410-397-27	FERRITE BEAD INDUCTOR	1.1UH		R24 R25 R26	1-216-025-00	METAL GLAZE 10 METAL GLAZE 10 METAL GLAZE 1K	00 5%	1/10W 1/10W 1/10W

The components identified by shading and mark ⚠ are critical for safety. Replace only with part number specified.





F. NO.	PART NO.	DESCRIPTION			REMA	<u>rk</u>	REF. NO.	PART NO.	DESCRIPTION			<u>R</u>	EMARK
D711 D712 D716 D717	8-719-911-19 8-719-911-19 8-719-911-19 8-719-121-24	DIODE 1SS119- DIODE 1SS119-	-25 -25				R726 R727 R728 R729 R730	1-249-422-11 1-249-422-11 1-215-410-00 1-215-410-00 1-215-410-00	CARBON METAL METAL	2. 7K 2. 7K 360 360 360	5% 1% 1%	1/4W 1/4W 1/4W 1/4W 1/4W	
J701 - 4	\1-251-2 <del>3</del> 9-21	<jack></jack>					R731 R732 R733 R734	1-535-303-00 1-535-303-00 1-247-739-11		(5.0MM) (5.0MM) 100		1/2 <b>W</b>	
L701	1-410-667-31	<coil></coil>	22UH				R738 R739 R740	1-247-807-31 1-247-807-31 1-247-807-31	CARBON	100 100 100	5%	1/4W 1/4W 1/4W	
L702 L703 L704 L705	1-535-303-00 1-408-609-41 1-535-303-00 1-408-609-41	LEAD, JUMPER INDUCTOR LEAD, JUMPER	(5.0MM) 33UH				R747 R749 R751	1-216-489-11 1-216-490-11	METAL OXIDE METAL OXIDE METAL OXIDE	27K 39K	5% 5% 5%	3W 3W 3W	F F
L706 L707	1-535-303-00 1-408-609-41	INDUCTOR	(5. OMM) 33UH				R753 R755 R756 R757 R758	1-249-429-11 1-249-427-11 1-249-427-11 1-249-427-11 1-249-419-11	CARBON CARBON CARBON	10K 6. 8K 6. 8K 6. 8K 1. 5K	5% 5% 5%	1/4W 1/4W 1/4W 1/4W 1/4W	
Q701 Q702 Q703		<pre><transistor> TRANSISTOR 25 TRANSISTOR 25 TRANSISTOR 25</transistor></pre>	SC2611				R759 R760	1-249-419-11 1-249-419-11		1.5K 1.5K		1/4W 1/4W	F
Q704 Q705	8-729-326-11 8-729-326-11	TRANSISTOR 25	SC2611 SC2611				RV701	1-230-641-11	<pre><variable adj,="" me*<="" pre="" res="" res,=""></variable></pre>		2.2M	I	
Q706 Q707 Q708 Q709 Q710	8-729-200-17 8-729-200-17 8-729-200-17	TRANSISTOR 2	SA1091-0 SA1091-0 SA1091-0	E			******	******	******	*****	****	*****	****
Q711 Q712 Q714	8-729-119-78	TRANSISTOR 2: TRANSISTOR 2: TRANSISTOR 2:	SC2785-HF				,	* A-1241-190-A	F1 BOARD, CO!		V-G25	M1 (RUS	S)
		<resistor></resistor>						1-533-223-11	CLIP, FUSE				
R701 R702 R703 R705 R710	1-244-941-00 1-249-496-11 1-249-496-11 1-216-392-11 1-215-899-11	CARBON CARBON METAL OXIDE	680K 100K 100K 1.8 15K	5% 1 5% 1 5% 1 5% 5	l/2₩	F F	C1501 A	<u> </u>	<capacitor></capacitor>	0. <b>22M</b> F	20%	250V	
R711 R712 R713 R714 R715	1-247-758-11 1-215-899-11 1-247-758-11	CARBON METAL OXIDE CARBON METAL OXIDE	3. 3K 15K 3. 3K 15K 3. 3K	5% 1 5% 5 5% 1	1/2W 2W 1/2W 2W 1/2W	F		* 1-580-843-11 * 1-580-843-11	PIN, CONNECTO		:		
R716 R717 R718 R719 R720	1-249-899-11 1-249-405-11 1-249-899-11 1-215-487-00 1-249-417-11	CARBON CARBON METAL	100 100 100 560K 1K	5% : 5% :	1/4W 1/4W 1/4W 1/4W 1/4W	F F F	- F1601 /	X1-532-465-31	<pre><fuse> FUSE: TIME=1. <resistor></resistor></fuse></pre>	AG (BET)	3.154	/250V	
721 2722 R723 R724 R725	1-215-491-00 1-249-923-11 1-215-489-00 1-249-417-11 1-249-422-11	CARBON METAL CARBON	820K 1K 680K 1K 2.7K	5% 1% 5%	1/4W 1/4W 1/4W 1/4W	F	R1601 A	£1-202-916-91	SOLID	5. <b>6</b> W	20%	1/2#	

The components identified by shading and mark  $\triangle$  are critical for safety.

Replace only with part number specified.



REMARK

REF. NO.	PART NO.	DESCRIPTION			REMARK	REF. NO.	PART NO.	DESCRIPTION	
R27 R28	1-216-071-00 1-216-025-00	METAL GLAZE METAL GLAZE		1/10W				REMOTE COMMANDER	
R29 R30 R31 R32 R33		METAL GLAZE	8. 2K 5% 100 5% 8. 2K 5%	1/10W 1/10W 1/10W 1/10W	7 7		1-473-323-11	. REMOTE COMMANDER	(RM-870)
R34	1-216-065-00 1-216-065-00 1-216-025-00 1-216-049-00 1-260-085-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 5% 4.7K 5% 100 5% 1K 5%	1/10W 1/10W 1/10W 1/10W 1/10W	7 7 7				
R41 R43 R44 R45 R46	1-216-063-00 1-216-295-00 1-216-061-00 1-216-021-00	METAL GLAZE CONDUCTOR, C METAL GLAZE METAL GLAZE METAL GLAZE	3.9K 5% HIP (2012) 3.3K 5% 68 5%	1/10W	T				
R47	1-216-021-00	METAL GLAZE	68 5%	1/10	ī				
		<crystal></crystal>							
X01	1-579-266-31	CRYSTAL VIBR	ATOR						
, <b>\***</b> *****	******	******	******	*****	*****				

### MISCELLANEOUS

1-544-453-21 SPEAKER (2CM)

1-504-305-11 SPEAKER (5X12CM)

A 2-742-305-11 SI EMBER (SATECH)

A 2-743-24-05 PICTIRE TIRE (M6KW 101)

A 2-451-46-13 BERECTION MRE (YZSTAS)

A 1-803-619-11 COM-THANANT TAXTION

A 1-544-06-22 CRR - DAMES MARK ARTHUR

### ACCESSORIES AND PACKING MATERIALS

\*\*\*

3-800-141-21 MANUAL, INSTRUCTION (KV-G25M1 (ME) 3-800-141-41 MANUAL, INSTRUCTION (KV-G25M1 (HK)/M11) 3-800-141-51 MANUAL, INSTRUCTION (KV-G25M1 (RUSS))

\*4-029-168-01 BAG, PROTECTION (KV-G25M11)
\*4-039-372-01 BAG, PROTECTION (KV-G25M1)
3-701-910-00 SCREW, SPECIAL (DIA. 3.8X20)

4-392-003-11 BAND, HOLD 4-392-004-11 CLIP

- 4-047-806-01 CUSHION (LOWER) (ASSY) (KV-G25M1)

  \*4-047-807-01 CUSHION (LOWER) (ASSY) (KV-G25M1)
- \*4-047-808-01 INDIVIDUAL CARTON (KV-G25M1)